HYDRAULIC PULLER

Operation Guide



1. Place the handle accessory into the handle clevis see above.



2. Tighten clockwise the Control valve knob



3. Center the Movable Cone in the object to be pulled. Then adjust the lock nut and jaws to proper position.



4. Important Notice : Before operating this unit, insure putting the safety net on(refer to the above)and covering the whole object completely.



5. One hand holds the Puller; the other pushes the handle up and down till the object is pulled out.



6-1. 360° Rotary pump handle, very easy to locate in the most convenient pumping position.



6-2. Loosen the Control valve knob to allow the Movable Rod return for next use.



7. The jaw accessory is available for 2-jaws and 3-jaws options.



8-1. 2-jaws application.



8-2. 3-jaws application.