

INSTRUCTION GUIDE

● HOW TO ASSEMBLE A LIFE GEAR BEAM TROLLEY ●

Please note 'BT' range of trolleys feature a spindle with left and right handed threads



STEP 1

Select the side plate marked with "L". The threaded drop bar, also marked with "L" features left-handed threads. To connect the two parts, turn the bar anti-clockwise.



STEP 2

Insert the bar and turn it until 2-3 threads are engaged.



STEP 3

Hold the second side plate in position and rotate the drop bar to engage the threads.



STEP 4

When the drop bar is turned the two sides move in and out to adjust to the required width.



STEP 5

Once the side plates are adjusted to the required width, secure them by tightening the lock nuts.